

# DS 10

The DS 10 is a portable pressure spraying device with integrated mixer unit for spraying suspensions and liquid cleaning, disinfection and decontamination agents. This means that the unit can be used for decontaminating personnel wearing protective suits, and smaller surfaces and objects.



With an operating pressure of up to 6 bar, the DS 10 mixes decontamination or cleaning agents with its integrated mixer unit, then emits fine quantities of spray through a stainless steel nozzle.

As products are mixed in the tank, liquid and powdery cleaning or decontamination agents can be blended into a solution or suspension. The mixer unit is activated easily using the handle of the hand pump.

As an enhancement to the DS 10, the unit can also be upgraded with an integrated compressed air connection, allowing the pumping action to come from a vehicle's pneumatic system, for example.

The DS 10 is manufactured from very high-quality stainless steel which is why the unit has an outstanding resistance to aggressive chemicals. Depending on the agent used, a 10-litre mixture can cover a surface area of up to 50 m<sup>2</sup>. The DS 10 is compact in size, which guarantees not only simple handling but also mobile and flexible operation.

The device has a low empty weight of 9.5 kg and is compact due to its small dimensions (219 x 210 x 730 mm).

## Special Features

- High-quality materials and workmanship
- Intuitive operating concept
- Minimised controls
- Can be operated wearing full protective gear
- Compact dimensions
- Quick to set up
- Can be used with virtually all commercially available cleaning and decon agents



# FUTURETECH

Kärcher Group